



# CRAZY BALLOON™

THE FUN GAME  
OF THE YEAR!!



(1) MOVE BALLOON FROM  
NEAR TO GOAL



(2) BETTER MOVE FAST  
OR THE 'BOGEY MAN'  
WILL GET YOU!!



(3) WATCH OUT!  
ONE WRONG MOVE  
AND YOUR BALLOON  
BURSTS!!

©TAITO CORP 1980

Printed in Japan



## TAITO CORPORATION

Mailing address: Central P.O. Box 11601

Tokyo, Japan

Cable Address: EPTRA TOKYO

Telex: J22931 Tokyo

Merchandise by



A game of strategy and skill.

The object of this new Taito game is to guide a delicate awoyag balloon through a maze of pin wheel obstacles.

You have 4 control buttons and you have the ability to move your balloon in any direction. Don't take too long, because if you are slow, a boggy man erupts on the screen and forces you to move.

Just when you think you have the maze all figured out, pin wheels attack your balloon forcing you to take evasive action.

Realistic western theme music enliven the experience.

#### PLAY INSTRUCTION

- \* Insert coin.
- \* Select game for one or two players.
- \* Maneuver balloon by use of 4 red control buttons.  
Top button moves the balloon vertically upwards, bottom button moves the balloon vertically downwards, right button moves the balloon horizontally to the right, left button moves the balloon horizontally to the left.
- \* Avoid all obstacles and move balloon from start to goal.
- \* Frame changes after each goal
- \* Balloon passing through obstacles scores the following points:

|                  |            |
|------------------|------------|
| Yellow obstacles | 500 points |
| Pink obstacles   | 300 points |
| Green obstacles  | 200 points |
| Blue obstacles   | 10 points  |
- \* Elapsed time decreases bonus points by 20 point increments.
- \* One balloon is awarded when score reaches 10,000 points.
- \* Game is over when 4th balloon bursts. (Four balloons per game)  
Hi-score player's name registration.
- \* Player's name can be registered on the screen.
- \* Alphabet (A-Z), "RUB" and "END" will appear on the screen.
- \* By pushing "LEFT" and "RIGHT" buttons, move line to any one character.
- \* Pushing "DOWN" button registers that character.
- \* "RUB" to erase any wrongly registered characters.
- \* "END" when registration is completed, move line under "END" and push "DOWN" button.

#### ADDITIONAL INFORMATION

There are 3 different levels of play in this game. The first 16 frames are in low gear and are the easiest.

The second 16 frames are in second gear, which means that the balloon swings wider and thus is much more difficult to move through the obstacles.

The third 16 frames are in high gear, and this means that the balloon swings even wider.

Different strategies are needed for different gears.